BJ-10e

PARTS CATALOG

Canon

Canon

FIGURE 1 PRINTER SET



NUM.	PART #	DESCRIPTION
1- 2	QA2-0503-000	CAP, CONNECTOR

FIGURE 2 PRINTER REAR PART



NUM.	PART #	DESCRIPTION
2 - 1	QA2-0301-000	COVER, BATTERY (BLACK)
	QA2-0302-000	COVER, BATTERY (WHITE)
2	QA2-0310-000	STAND, PRINTER (BLACK)
	QA2-0324-000	STAND, PRINTER (WHITE)
3	QA2-0308-000	FOOT, RUBBER (BLACK) (2)
	QA2-0418-000	FOOT, RUBBER (WHITE) (2)

Canon

FIGURE 3 TOP & INNER COVERS



NUM.	PART #	DESCRIPTION
3 - 1	QA2-0307-000	COVER, TOP (BLACK)
	QA2-0365-000	COVER, TOP (WHITE)
2	QF1-5031-000	COVER, INNER (BLACK)
	QF1-5042-000	COVER, INNER (WHITE)
3	QS1-1483-000	LABEL, INSTRUCTION (WHITE)
	QS1-1484-000	LABEL, INSTRUCTION (BLACK)

FIGURE 4 UPPER COVER



NUM.	PART #	DESCRIPTION
4 - 1	QA2-0305-000	KEYTOP (BLACK)
	QA2-0347-000	KEYTOP (WHITE)
2	QA2-0306-000	INDICATOR, LED (2)
3	QA2-0303-000	COVER, UPPER (WHITE)
	QA2-0304-000	COVER, UPPER (BLACK)
4	QA2-0541-000	LABEL, GROUNDING

FIGURE 5 LOGIC CARD



NUM.	PART #	DESCRIPTION
5 - 1	QG2-2314-000	CARD, LOGIC

FIGURE 6 PRINTER UNIT



NUM.	PART #	DESCRIPTION
6 - 1	QA2-0326-000	SWITCH, BATTERY (WHITE)
	QA2-0390-000	SWITCH, BATTERY (BLACK)
2	QG1-5054-000	UNIT, PRINTER
3	QH8-8302-000	SENSOR, PAPER

FIGURE 7 POWER SWITCH



NUM.	PART #	DESCRIPTION
7 - 1	QA2-0312-000	HOLDER, SWITCH
2	QA2-0311-000	SWITCH, POWER (BLACK)
	QA2-0376-000	SWITCH, POWER (WHITE)

FIGURE 8 LOWER COVER



NUM.	PART #	DESCRIPTION
8-1	QG2-2315-000	UNIT, DC INLET
2	QA2-0309-000	COVER, LOWER (BLACK)
	QA2-0374-000	COVER, LOWER (WHITE)
3	QA2-0313-000	FOOT, RUBBER (BLACK) (4)
	QA2-0416-000	FOOT, RUBBER (WHITE) (4)

FIGURE 9 PURGE UNIT



NUM.	PART #	DESCRIPTION
9 - 1	QA2-0321-000	BELT, CARRIAGE DRIVE
2	QF1-5037-000	MOTOR, CARRIAGE
3	QA2-0323-000	SPRING, BELT TENSION
4	QG1-5075-000	UNIT, PURGE
5	QA2-0325-000	STOPPER, CARRIAGE SHAFT
6	QA2-0657-000	SLIDER

FIGURE 10 RIBBON CABLE HOLDER



NUM.	PART #	DESCRIPTION
10 - 1	QA2-0322-000	HOLDER, CARRIAGE RIBBON CABLE

FIGURE 11 CARRIAGE (1)



NUM.	PART #	DESCRIPTION
11 - 1	QA2-0373-000	COVER, HOOK
2	QA2-0372-000	LEVER, HOOKING
3	QA2-0371-000	SPRING
4	QA2-0370-000	HOOK, BJ CARTRIDGE
5	QA2-0364-000	COVER, CARRIAGE
6	QA2-0363-000	HOLDER, LEAD PIN

FIGURE 12 CARRIAGE (2)



NUM.	PART #	DESCRIPTION
12 - 1	QA2-0362-000	PIN, LEAD
2	QG1-5059-000	SCREW, LEAD

FIGURE 13 RIBBON CABLE



NUM.	PART #	DESCRIPTION
13 - 1	QA2-0369-000	HOLDER, RIBBON CABLE (LOWER)
2	QA2-0368-000	HOLDER, RIBBON CABLE (UPPER)
3	QA2-0367-000	PAD, CONTACT
4	QA2-0366-000	BASE, CARRIAGE
5	QY6-0021-000	CABLE, CARRIAGE RIBBON (W/HP SENSOR)

FIGURE 14 CARRIAGE GUIDE SHAFT



NUM.	PART #	DESCRIPTION
14 - 1	QF1-5032-000	SHAFT, CARRIAGE GUIDE
2	QA2-0331-000	HOLDER, GUIDE SHAFT

FIGURE 15 PAPER FEED PART (1)



NUM.	PART #	DESCRIPTION
15 - 1	QA2-0415-000	ROLLER, PRESSURE (4)
2	QA2-0330-000	PLATE, PRESSURE (4)
3	QG1-5063-000	ROLLER, EJECT (2)
4	QA2-0405-000	SHAFT, ROLLER (2)
5	QG1-5062-000	ROLLER, TRANSMISSION (2)
6	QA2-0404-000	PLATE, PLATEN
7	QA2-0420-000	SEPARATOR, PAPER

FIGURE 16 PAPER FEED PART (2)



NUM.	PART #	DESCRIPTION
16 - 1	QA2-0387-000	STABILIZER, FEED ROLLER
2	QA2-0392-000	HOLDER, LEAD SCREW
3	QA2-0386-000	DIAL, ADJUST
4	QA2-0388-000	LOD, RELEASE
5	QF1-5038-000	ROLLER, FEED
6	QA2-0384-000	CRANK, RELEASE
7	QA2-0385-000	HOLDER, FEED ROLLER

FIGURE 17 PAPER FEED MOTOR



NUM.	PART #	DESCRIPTION
17 - 1	QA2-0332-000	HOLDER, FEED MOTOR CABLE
2	QH4-4020-000	MOTOR, PAPER FEED
3	QA2-0399-000	GEAR, SLOWDOWN
4	QA2-0400-000	LEVER, RELEASE

FIGURE 18 PINCH ROLLER



NUM.	PART #	DESCRIPTION
18 - 1	QA2-0381-000	LEAF SPRING, PINCH ROLLER (2)
2	QA2-0383-000	SHAFT, PINCH ROLLER RELEASE
3	QA2-0505-000	HOLDER, PINCH ROLLER (2)
4	QA2-0506-000	ROLLER, PINCH (2)

FIGURE 19 PAPER FEED BASE



NUM.	PART #	DESCRIPTION
19 - 1	QA2-0380-000	BASE, PAPER FEED
2	QA2-0391-000	ABSORBER, INK
3	QA2-0333-000	ABSORBER, INK
4	QA2-0329-000	HOLDER, PRESSURE PLATE (4)
5	QA2-0327-000	CHASSIS
6	QF1-5036-000	SHAFT, PRESSURE PLATE RELEASE
7	QA2-0328-000	LEAF SPRING, PRESSURE PLATE (2)

NUM.	PART #	DESCRIPTION